Sharing. Intelligence. Greatness.

KEY FEATURES/TECHNICAL SPECS

- 4G LTE
- 4.8" HD Super AMOLED™ Touchscreen
- 8.0MP Camera With Flash/1.9MP Front-Facing Camera
- Powerful 1.5GHz Dual-Core Processor
- Android™ 4.1, Jelly Bean
- Wi-Fi® With Bluetooth® Wireless Connectivity
- NFC Capability
- Dimensions: 5.4" x 2.8" x 0.3"
- Weight: 4.7 Ounces

MEMORY

- 2GB RAM/16GB ROM
- External Memory Card Supports Up to 64GB (not included)

Samsung GALAXY S III

Tips & Tricks

SHARE CONTENT ON YOUR TV AND STEREO USING ALLSHARE® PLAY

AllShare Play is perfect for sharing any of your favorite songs and user-generated content, like vacation videos and family reunion photos. To get started with AllShare Play, you need a Samsung account. If you don't have one, visit allshareplay.com to sign up.

ENABLE MOTION GESTURES

Customize how you interact with your Samsung Galaxy S® III and enable the motion gestures you want to use. To enable hand gestures and learn how to use them, touch **Settings**, then **Motion**. Touch the name of any gesture to view a tutorial. To enable eye-tracking features, touch **Settings**, **Display**, then **Smart Stay™**.

MAKE A QUICK CALL FROM A TEXT MESSAGE

Reading a message from a friend, but want to respond with a call? Enable the **Direct Call** gesture so you can just lift the phone to your ear while in the message screen, call log or contact details to dial the contact displayed on the screen. To enable the **Direct Call** gesture, touch **Settings**, **Motion** and slide the bar to green (ON). Touch **Motion**, then touch the box next to **Direct Call**. The green check mark means the feature is ready to use.

MULTITASK WITH VIDEO PICTURE-IN-PICTURE

When you need to check your email, send a text or surf the web while watching a video, there's no need to pause the action anymore. Just touch the **picture-in-picture** icon within the media player, and you'll be able to move the screen around and multitask while you watch. Picture-in-picture works with content that plays in the native video player only.

MUTE AN INCOMING CALL

When the **Turn Over to Mute** gesture is enabled in your **Motion** settings, you can simply turn the phone over to mute the ringer of an incoming call, alarm or alert tone.

SHINE A LIGHT

You'll always have a flashlight handy, thanks to the Assistive Light widget on your Samsung Galaxy S® III. This widget turns your camera's flash into a flashlight whenever you need one. To add the Assistive Light widget to your Home screen, touch **Apps**, select the **Widgets** tab, then touch **Assistive Light**.

ACCESSING GOOGLE PLAY™ STORE AND DOWNLOADING A NEW APP

1. From the Home screen, touch the **Play Store** icon or touch **Apps**, then touch the **Play Store** icon.
2. If not already logged in to your Google™ account, touch **Existing**. Touch **New** and follow the on-screen prompts if you need to create an account.
3. Touch **Sign in** and enter your Google account information.
4. Touch **Accept** to agree to Play Store's terms of service.
5. Browse through the categories, find an application you're interested in and touch the name.
6. Touch **Download** if the app is free, then **Accept & download**. If it's a paid app, follow the on-screen prompts in order to purchase and download the app.

PAIRING BLUETOOTH® DEVICES

1. Verify that Bluetooth® is active.
2. Place the other Bluetooth device in discoverable mode. (See the device user manual for more information.)
3. Touch **Scan for devices**. Your device displays a list of discovered in-range Bluetooth devices.
4. Touch a device from the list to initiate pairing.
5. Enter the passkey or PIN code, if needed, and touch **OK**.
6. The external device must accept the connection; then enter your device's PIN code.
7. Once successfully paired to a device, the Bluetooth icon displays in the Status area.

TAKING PICTURES

1. Swipe the **Camera** icon when the screen is locked, touch the **Camera** icon on the Home screen or touch **Apps**, then **Camera,** to activate.
2. Using the display as a viewfinder, point the camera lens at your subject.
3. When the image you wish to capture appears in the display, press the **Camera** button or, if S Voice™ is activated, just say "cheese" to take a picture.
4. After taking the picture, you can touch the thumbnail image to view, share or upload your picture.

CAPTURING VIDEOS

1. Swipe the **Camera** icon when the screen is locked, touch the **Camera** icon on the Home screen or touch **Apps**, then **Camera,** to activate.
2. Slide the **Camera** mode button from picture to video.
3. Using the display as a viewfinder, point the camcorder lens at your subject.
4. When the image that you wish to capture appears in the display, press the **Record** button to start recording. Press the **Record** button to stop recording.
5. After recording your video, you can press the thumbnail image to view, edit and share your video.

boost mobile

© 2013 Samsung Telecommunications America, LLC. Samsung, Galaxy S, AllShare, S Voice, Smart Stay and Super AMOLED are all trademarks of Samsung Electronics Co., Ltd. Google, Android, Google Play and other marks are trademarks of Google Inc. Appearance of device may vary. Screen images simulated. Other company names, product names and marks mentioned herein are the property of their respective owners and may be trademarks or registered trademarks. Printed in U.S.A.

SAMSUNG